






1x Lino P3




1x Lino P5



2x Lino P3/P5



3x Lino P5



## QUICKSTART Leica Lino P3/P5



2



Leica Lino P3

3

4

1

### Buttons

- 1 LASER
- 2 Lock ON/OFF
- 3 Battery voltage too low
- 4 Laser ON

- when it has to be **right**



**Leica**  
Geosystems



Laser on



Laser off/lock



Laser class 2 in acc. to IEC 60825-1

[www.leica-geosystems.com](http://www.leica-geosystems.com)

