

angle gauge

Easy removal and transfer of angles and determination of miters

The angle bevel is used to measure internal and external angles. These are automatically halved during measurement. This makes it possible to easily determine the mitre angle and set it on other tools. Workpieces can thus be quickly scribed.







Removal and transfer of angles

Features

- Made of aluminium
- Removal and transfer of angles
- Suitable for internal and external angles
- Simple determination of mitres

Specifications

Dimensions Scaling Pitch distance Warranty / Months EAN 440 x 170 mm 0° - 170° 5° @ 0°-40° / 2° @ 40° -170° 24 4012589871014